

FIG. 1




FIG. 2




FIG. 3

User Menu

Setting Menu	Code
Subtitle	0001(KOR.)
Audio Language	1002(ENG.)
Audio Format	2002(6CH)

Subtitle Menu

Subtitle	Code	Default
KOR	0001	←
ENG	0002	
SPA	0003	
FRA	0004	
.	.	
.	.	

Audio Language Menu

Audio Language	Code	Default
KOR	1001	←
ENG	1002	
SPA	1003	
FRA	1004	
.	.	
.	.	

Audio Format Menu

Audio Format	Code	Default
2CH	2001	←
6CH	2002	
DTS	2003	
.	.	
.	.	

FIG. 4

